

Why is there cracking on my scoring job?

Written by Web Master
Friday, 22 July 2011 10:30 -

When a job is coated with UV then scored and folded, the job may begin to crack. During use, the cracks will become bigger, and the ink may start to chip off. Cracking is normal when coated jobs are scored and folded. Ordering the job without UV will help but may not prevent this. As the job is used and folded more and more, cracking will eventually happen.